

How to Select the Right Inverter for your Vehicle or Boat



TECH DOCTOR™

Size IS everything!
By Xantrex Tech Doctor

In an industry where size is everything — larger engine, smaller accessories, and lighter weight — it's easy to make inaccurate assumptions and create undesirable problems for yourself. Unfortunately, in my line of work, I have witnessed many instances of undersized inverters being used by operators in an effort to save a buck. When operating below recommendation, the electrical system is far from efficient and can prove troublesome.

So...the million dollar question for this edition of Tech Doctor is: What size inverter SHOULD I have in my system? And the obvious answer is...well, it's really NOT so obvious! The truth is, this decision all depends on exactly how you want and/or intend to use your inverter. Let's consider some questions to help you understand how to make the best choice for your unique application.

Q: How much load (electronics/appliances) do you want to run when disconnected from shore power?

TECH DOCTOR: It's important to look at the wattage draw of ALL of the appliances, plus to leave some room for future additions. If you have a 1000 W A/V system, for example, and install a 1000 W inverter, you're probably asking for problems. You see, inverters are rated for their optimum performance under optimum conditions. If the inverter gets hot, or the battery voltage drops, the inverter's ability to feed a constant 1000 W may be compromised. Also, surges in power draw (such as turning on a motor) can affect the ability of the inverter to maintain proper output.

Consider this example and accompanying formula.

If you are going to plug-in two devices simultaneously, add up the total wattage of both devices, and then add at least 50% more to account for peaks or spikes in the power draw.

- (1) Monitor 100 watts
- (2) Portable lights 100 watts

Recommended size of inverter:

$$200 \text{ watts (100 watts + 100 watts)}$$

$$+ 100 \text{ watts (0.50 X 200 watts)} = 300 \text{ watts}$$

Obviously if you know for sure that two loads are never going to run at the same time, your calculation can include the higher draw load exclusively. My advice? Use common sense here, but always

err on the side of the inverter. After all, nobody wants to have to remember to turn off the entertainment center when using the microwave to pop the popcorn! If there is any possibility of the loads running concurrently, include both in your calculations.

Q: What are other important considerations?

TECH DOCTOR: Some loads, like motors or other inductive loads, have an extremely high demand at start-up, some as high as 5-times their rated power (check with appliance manufacturer for more information). Most inverters have a fairly high surge rating which is their ability to feed short-term high power to get these loads started. There's no sure-fire way of knowing the appliances surge demand, without testing, since such data is not labeled.

While high frequency inverters are cheaper and more efficient, low frequency inverters can surge better, and for a longer period of time. However, depending on your load mix, it may be better to use a larger, high-frequency inverter than a smaller, low-frequency inverter to provide instant start-up current for some loads, plus available power to run all loads at once.

Q: What is a sine wave inverter? Does it have to do anything with inverter sizing?

TECH DOCTOR: It is not directly related to inverter sizing, however you must take into account the type of electronics and appliances you want to run using the inverter.

Let me briefly explain the two types of inverters. You could refer to my previous article "Sine Wave v/s Modified Sine Wave: Which is better?".

True Sine Wave Inverters produce AC power that is similar to power available from the public utility grid system. They are expensive compared to modified sine wave inverters, but they produce quality output that operates the most sensitive and sophisticated electronics. Modified Sine Wave Inverters produce AC power that is sufficient to run most electronics. However, the laser printer, fax machine, laptop, plasma television set and medical equipment may not run properly with modified sine wave power.

Approximate power requirements for commonly used electronics:

Example	Power (W)	Example	Power (W)
Computer System	200	Microwave Oven	1200
Power Drill	400	Large Vacuum	1200
Coffee Maker	900	Circular Saw	1500
Toaster	800	Blender/ Juicer	1000

Want to share this in your publication?

*Xantrex Technology provides this technical editorial for reproduction in your publication. Editorial content (other than headline) may not be edited. Author byline must be included. For back issues of Tech Doctor which are available for editorial reproduction, please visit www.xantrex.com